



T1108-3.5K Trailer Plans

Parts Required To Build Trailer – 3.5K Capacity

- | | |
|-------------------------|---------------------------|
| 1) 80072 | 2" A-Frame Coupler |
| 1) D35-72X58-I-US-72-42 | 3.5K Axle W/Springs |
| 1) HGR-104-00 | Hanger Kit |
| 1) A/P-122-00 | Attach Parts Kit |
| 2) 15545WS/205DC | 15" Tire & Wheel Assembly |
| 2) 2105 | 9 x 32" Fender |
| 2) 2712-32-16 | Fender Back |
| 1) 175000 | A-Frame Jack |
| 1) 018173-24 | Jack Foot |
| 40) 1025373 | 5/16 x 2-1/2 Floor Screw |
| 1) 540 | Light Kit |
| 2) SC1427 | Safety Chain |
| 1) T1108 | Trailer Plan Set |

Complete Trailer Parts Kit – All You Need Is The Metal & Materials For Flooring. Trailer Plans Have Complete Step By Step Instructions With Diagrams To Show You How To Construct Your Trailer. We Also Will Provide A Dexter Pro Spec That Will Show Axle Configuration And Measurements.

Call for the Kit Cost!